

Installation Guide

安裝說明書

VEHICLE APPLICATIONS
適用車型

AUDI A1 2010-present
SKODA FABIA 3rd 2015-present


PART NO. 8641

Contents 內含配件

※ Please apply hand tools for installation
安裝過程請使用手動工具

1. Front Sway Bar 22mm 前防傾桿 1PCS

2. Stabilizer Bush 防傾桿橡皮 2PCS



Installation tips 安裝提示



1. Removal of front sub-frame is required to install front sway bar.

須拆下前工字樑，以利更換前防傾桿

2. Before installing the front sub-frame, it is advised to place the RH sway bar bolt in advance. As shown on the left figure. (To prevent locking position of bolt is blocked by the RH drive shaft.)

安裝工字樑之前，建議先把右側固定防傾桿螺絲預先放入，如圖（避免右側傳動軸擋住，螺絲鎖入位置）



3. 4-wheel alignment is required after installation.

請務必進行電腦四輪定位校正

Warning 安全提示

Installation should only be performed by licensed mechanics who have the necessary skill and tools to do the job correctly and safely.

安裝需由合格的專業技師及工具執行，以確保安裝過程的正確與安全

When swapping the suspension kits, be sure to note the routing and mounting position of all wires, cables and bolts orientation, certain damage might be caused by reinstalling differently from the original factory position. Please refer to factory manual for proper installation and safety stands.

當更換您車輛的懸吊套件時，請記下您的線組與管線安裝位置，非原廠相同的安裝位置可能會造成元件之損壞，造成車輛的危險。請參考原廠車輛手冊



TEL: +886 3 5370822 FAX: +886 3 5373027
E-MAIL: info@hardrace.com WEBSITE: WWW.HARDRACE.COM

