

Installation Instructions

安裝說明書

REAR SWAY BAR
後防傾桿, 22mm
#8607

Application 適用車型

Honda CR-V 2nd RD4/5/7
Honda Stream 1st RN1-5

Components 內含配件

- | | |
|-----------------------------|------|
| ① Sway bar 防傾桿桿身..... | 1pcs |
| ② Bushing 橡皮..... | 2pcs |
| ③ Bushing clamp 橡皮固定環..... | 2pcs |
| ④ Bolt 螺絲 (M8x1.25x20)..... | 4pcs |

Caution 注意事項

- Installation is recommended to be performed by licensed mechanics with necessary tools to ensure safety. Incorrect installation may cause injury, damage to the product or vehicle. 安裝建議由合格的技師及工具執行以確保安全。安裝錯誤可能對人員、產品及車輛造成傷害。
- Note the routing of wires and cables before installation, or please refer to factory manual. 安裝前請事先記下線路的安裝路徑及位置以維持原廠配置。有疑問時請參考原廠手冊。
- Tighten bolts and nuts firmly by using handtools, and with specified torque if mentioned. 安裝過程請使用手動工具確實鎖緊螺帽及螺絲。如有特別註明請依照說明指示的扭力上鎖。

Instructions 安裝說明

1. Raise and safely support the vehicle to access rear subframe.
將車輛升起後找到後副車架。
2. Remove the factory sway bar front subframe and end links.
將原廠防傾桿從副車架以及李仔串卸下。
3. Install the supplied sway bar bushings and bushing clamps onto the Hardrace sway bar.
將配件防傾桿橡皮及橡皮固定環裝至Hardrace防傾桿。
4. Install the new sway bar to the subframe.
將防傾桿安裝至副車架。

Note 備註

CR-V:

Install bushing clamps using supplied bolts.
使用配件螺絲安裝固定環

Stream:

Install bushing clamps using factory bolts.
使用原廠螺絲安裝固定環

5. Reinstall the sway bar end links. Use inner holes for stiffer and outer holes for softer setup.
安裝李仔串。使用內側孔安裝調整至較硬或使用外側孔調整至較軟。

Torque Spec 上鎖扭力值:

M8: 60Nm

M10: 80Nm

