Installation Instructions

安裝說明書



- 1. Loosen rear control arm inner bolts on both sides. (See figure 1) 鬆開兩側後下控制臂內側螺絲。(參考圖表一)
- 2. Position the brace on the vehicle. 安裝結構桿。
- 3. Tighten the bolts to secure the brace. 鎖緊螺絲以將桿身固定。



See figure 1 (參考圖表一)



■Illstration of installed state 安裝完成示意圖



